



*Mailing Address*  
1455 Lexamar Drive, Boyne City, MI 49712

*Toll Free* 888-999-3290  
*Office* 231-582-1020  
*Fax* 231-582-7324  
*Email* [imtech@freeway.NET](mailto:imtech@freeway.NET)  
*Web* [www.gag-simtech.com](http://www.gag-simtech.com)

## INSTALLATION INSTRUCTIONS FOR SIMTECH ORIFICE SHIELDS

**PART #'S: STF-106/all sizes, STF-106D/all sizes, STF-106TDS/all sizes**

Simply snap orifice shield over pipe making sure it is centered over the lateral hole. A felt tip marker works well in establishing a reference mark for this purpose. This mark can again be used to double check the location just before final covering. When in place, the slots of all styles of orifice shields should be positioned towards the ground.

**Note: PVC cement may be used on these SIMTECH Orifice Shields to positively secure the orifice shields to the laterals. We recommend the use of PVC cement on the orifice shields to prevent any chance they get bumped out of place while under construction.**

This is one of many performance products offered by SIMTECH FILTER, INC. to keep your pressure systems working at 100% efficiency.