



Ultra Rib Pipe Riser to Riser Adapter Ring Installation Instructions

Step 1 Apply adhesive to corner cove around the entire circumference of the ring.



Tips:

Try the ring on both of your pipe sections without adhesive to make sure it properly fits them both.

Use a 3/8" bead of pliable adhesive for best results.

Step 2 Insert into existing riser, adhesive side down. (splice first is easiest)



Step 3 Apply adhesive to the other side of the adapter ring as in Step 1.



Tips:

Use a 3/8" bead of pliable adhesive for best results.

Step 4 Stack additional riser onto adapter ring.



Tips:

Allow proper curing time for the adhesive being used.

All risers should be backfilled with sand to prevent frost action from lifting the risers in cold climate areas. Clay and muck have very high expansion characteristics when frozen and should not be used to backfill.

Note: Sim/Tech Filter also offers a cut-off saw for cutting ultra-rib pipe smoothly, evenly and in less than 15 seconds.

