



Address
1455 Lexamar Drive
Boyne City, MI 49712

Toll Free 888-999-3290
Office 231-582-1020
Fax 231-582-7324
Email sales@gag-simtech.com
Web www.gag-simtech.com

STF-103B INSTRUCTIONS

1. Leaving the bristles of the STF-103B screen removal tool exposed, slide the unit into the filter housing where the filter screen is located until the bristles are flush with the top of the filter screen.



2. Now pull the filter screen out of the filter housing and service/clean it as needed. Release the STF-103B screen removal tool from the filter screen by sliding the PVC handle down over the bristles.



3. After cleaning off the filter screen replace it by following step 1 again then sliding the filter screen back into the filter housing. To release the filter screen from the handle's grip again, slide the PVC handle down over the bristles.



NOTE: when the STF-103B is not in use, leave the bristles exposed to keep them from being crushed by the PVC sliding handle.

When using a filter screen not equipped with a filter sock, the bristles of the STF-103B can also serve as a cleaning tool for the filter screen.